



# ***Speedy Concrete Repair***

***"Rescuing concrete, one slab at a time."***

**Speedy Concrete Repair, LLC**

**Phone: 770-904-9065**

**Toll Free: 877-891-1865**

**Email: [info@speedyconcretereprair.com](mailto:info@speedyconcretereprair.com)**

## **SCR-J85C**

**Follow repair area prepping instructions before beginning to install material.**

**Safety glasses/goggles, gloves and dust mask recommended before installing joint material.**

***Assembly and Installation for SCR-J85C***

***SHAKE CARTRIDGE WELL BEFORE USING***

***Prepping*** - All old joint filler, debris and moisture should be removed before installing material. Surface temperature to apply is between 32°F to 150°F.

***Assembly*** - remove nut from top of cartridge. Pull out plug and place static mixer on top of cartridge securely. Slide nut back down over static mixer and screw down to tighten firmly. Place in 2 component 300ml x 300ml applicator.

***Installation*** - Using a dustless concrete saw, diamond blade saw joint vertically at 90° angle to minimum of one inch depth. Take assembled cartridge point straight up and purge air until material reaches the top of the static mixer. Point straight down into a disposal container and squeeze applicator handle a few times to purge a small amount. Place static mixer into joint and begin squeezing handle to apply. Keep a steady flow and don't stop movement. Overflow a small amount of material in the joint. Shave flush to the floor in 30 minutes.

**[www.speedyconcretereprair.com](http://www.speedyconcretereprair.com)**